



Ucam-Polar Link

Seamless Ucam/Polar integration using the best of both worlds

USA / CANADA
+1 (503) 356 5270
ken@polarinstruments.com

ASIA / PACIFIC
+65 6873 7470
terence@polarinstruments.com


UNITED KINGDOM / EUROPE
+44 23 9226 9113
neil@polarinstruments.com

JAPAN
+81 45-339-0155
ttsuji@polarinstruments.com


KOREA
+82 2 2644 2493/4
jsbae@polarinstruments.com

GERMANY, AUSTRIA, SWITZERLAND
+43 7666 20041-0
reischer@polarinstruments.com


REST OF WORLD
Polar Instruments Ltd
(Head office)
Garenne Park, Guernsey
UK. GY2 4AF
United Kingdom
+44 1481 253081
martyn@polarinstruments.com



Load Job



Load Stackup



How it works:

- Load job data into Ucam v8 and define layers
- Import Ucam job file into Speedstack 2009
- Use Polar Speedstack PCB to define materials
- Import stackup (.stkx file) into Ucam

- Eliminate double work
- Saves up to 15 minutes per job Polar time
- Saves up to 1 hour per job Ucam time
- Only one material database to maintain
- Less errors = Less scrap = Less cost

© Polar Instruments 2009.
Polar Instruments pursues a policy of continuous improvement. The specifications in this document may therefore be changed without notice.
All trademarks recognised.